

Philips
Micro Hi-Fi System

MP3/WMA

MCM393



The new classic

with USB Direct playback

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM393 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with USB Direct playback.

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB devices
- Plays MP3/WMA-CD, CD and CD-RW music
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost delivers deep and dramatic bass
- 2x15W RMS/2x30W music power

Start the day your way

- Wake-Up and Sleep Timer
- The digital tuner has 40 presets for extra convenience

Refined in sound and look

- Elegant wood-finish speakers
- Easy-to-use remote control included

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x15W RMS / 2x30W music power
- **Sound Enhancement:** Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- **Main Speaker:** 2 way, Bass Reflex Speaker System, 4" woofer, Speaker grilles detachable

Audio Playback

- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **Disc Playback Modes:** 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- ID3-tag support
- **Loader Type:** Tray
- **USB Direct Modes:** Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- **Tuner Bands:** FM Stereo, MW
- Auto digital tuning
- **RDS:** Station Name, Radio Text, RDS Clock Set
- **Station presets:** 40
- **Tuner Enhancements:** Auto Store

Connectivity

- **Aux in:** Line in

Product highlights

USB Direct music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Date of issue 2007-02-22

Version: 1.0

I2 NC: 8670 000 30261
EAN: 87 12581 33680 6

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com